

740MX

Sealed Steel Series




The powerful **740MX** is a lightweight motor with power to maintain high speed on your tool path. The direct drive turbine does operations 24/7 with great durability. The rigid steel housing enables you to mount anywhere and is sealed for contaminated environments.

Get governed high speed under load, not speeds that drop when your tool starts cutting. Eliminate lubrication, vanes, gears and brushes and accelerate your production rate.

Mountable area of Ø 40mm OD by 133mm. Completely sealed with hose exhausts.

740MX Dimensions



All fittings, couplings, and hoses must have a minimum of 6mm internal diameter.

A	1.0" (25.40mm)	C	5.25" (133.35mm)
B	Ø 1.57 (40mm)	D	7.0" (177.8mm)

740MX Specifications

Speed RPM	40,000	50,000	65,000
Power Rating hp (kW)	0.3 (0.22)		0.4 (0.30)
Inlet Air Pressure	90 PSI (6.2 Bar)		
Air Consumption Idle cfm (l/s)	5 (2.36)	6 (2.83)	
Air Consumption Working Flow cfm (l/s)	7 (3.30) - 10 (4.72)		
Air Hoses and Fittings Minimum Size	6mm ID		
Sound Level	Less Than 78 dBA		
Max Shank Capacity	ER11 UP - 1/4" (6mm)		
Motor Weight	34 oz (0.96 kg)		

740MX Series Part Numbers

ER11 UP - 1/4"		ER11 UP - 6mm	
Speed RPM	Part Number	Speed RPM	Part Number
40,000	70114	40,000	70115
50,000	70118	50,000	70119
65,000	70122	65,000	70123

Accessories

Model	Part Number
Low Flow Filter Regulator / Extractor	30006
Tube 10mm O.D. - 6.5mm I.D. (order by foot)	16508
Hose & Fitting - 8mm O.D. - 5mm I.D. - 12'	30043

Equipment Included

- 740MX Motor
- ER11 UP Collet System (1/4" or 6mm)
- Collet Wrenches
- Low Flow Filter Regulator / Extractor
- Air Hose
- Fittings
- Carrying Case

Standard Equipment

ER11 UP Collet System (1/4" or 6mm collet.)

Oil-free 90 psi / 6.2 bar clean, dry air supply required.

Tel:+1.561.994.0500 • www.airturbine.com • ask@airturbine.com

Supply is subject to Air Turbine Technology Inc. (ATT) distributor policies and upon terms and conditions contained in the ATT distributor agreement. Subject to availability, change of specifications, price and terms without notice. Always use a 0.3 micron filter/extractor and check specified air flow. 6.2 Bar / 90 psi clean, dry, oil-free air only. Use eye protection and follow safety instructions. All specifications approximate. © 2024 Air Turbine Technology, Inc. All rights reserved.


Air Turbine Motors® Quick User Notes and Setup Guide

Motor Name - Sealed Steel Series



Initial Installation

Install a new dedicated clean air line from the included Filter/Regulator to your Air Turbine Motor® as shown below. **Ensure all air lines, couplings and fittings meet the minimum internal diameter of 6mm.** If working in a wet environment be sure to install exhaust hoses as shown below. Internal diameters of exhaust hoses must be no smaller than 6mm internal diameter. Any connections smaller than 6mm will restrict air flow and reduce power to your Air Turbine Motor®.



Air flow restrictions (such as air leaks and obstructions) cause under power performance and your cutting tool to drag through the material, damaging the bearings. **Some fittings with nominal internal dimensions may have an internal diameter passage that is smaller than stated and restrict air flow and power.** It only takes one fitting with too small an internal diameter to reduce air flow and reduce power of your Air Turbine Motor®.

Air Requirements


Do not oil or lubricate. Use dry, clean, oil free 90 psi (6.2 Bar) air supply only.

Ensure there is sufficient volume of compressed air flow at 90 PSI / 6.2 Bar with **7 (3.30) - 10 (4.72) CFM (L/S)** to maintain working air consumption. Depending on application, consider peak or stall capacity consumption.

Air flow volume increases on demand to keep rotation at the high speed when your tool starts to cut. Air Pressure and flow volume must therefore be available on demand and remain constant with no drop over time or when cutting. Avoid Pressure below 90 PSI / 6.2 Bar, which causes the tool to be dragged through the material, causing rapid bearing wear and underpowered performance. More than 100 PSI / 6.9 bar pressure will burst the turbine power producer. Air Pressure and flow must remain constant with no drops under cutting load. Insufficient flow will cause the rotation of your tool to slow or stop suddenly, damaging the bearings. If a drop in PSI (Bar) occurs below 90 PSI (6.2 Bar), your compressor may not have enough CFM (L/S) to power the Air Turbine Motor® or there is a flow restriction in the air line.

Mounting your Air Turbine Motor® in a Lathe or Robot

It is very important your fixture is not clamped over the bearings. Incorrect positioning or over tightening of the clamp on your Air Turbine Motors® steel barrel results in pressure on the bearings causing premature failure. To avoid this error in installation refer to the dimensional drawing for your model on the other side of this page.



Scan to consult full user instructions.

Maintenance

Your Air Turbine Motor® must be run at least 10 minutes every 30 days from manufacture date to maintain optimal performance. Run at least 10 minutes before initial use. The airline must be impeccably clean with no coupling or hose smaller than 6mm internal diameter. The included 0.3 micron filter extractor regulator combination is a necessary accessory for Air Turbine Motors® to eliminate impurities in your air supply. Contamination will damage your turbine components and require repair. **Filter elements need to be changed and extractor drained in regular maintenance cycles.** Replacement elements are available in the Accessories section on our website.

Operation

Purge the line of contamination and run at least 10 minutes before initial use to ensure the bearing lubrication does not solidify.

Always monitor Air Pressure Gage during operation of your Air Turbine Motor®. The key to successful high-speed machining and optimized tool performance is to program light passes at very high feed rates. Start with a light pass observing surface finish quality and gradually step down or increase your rate of advance for optimal cutting conditions. Do not try to cut too aggressively. You will overload your turbine causing your cutting tool to stall or drag in the material. Dragging your tool or a sudden stop will cause stress to the bearings and will result in the turbine requiring a repair. In certain applications, ensure that the material goes through a cooling process before you begin drilling with your 740MX. This is to prevent heat from transferring from the material to the cutting tool and the bearings, and reduces the risk of premature failure.

The 700 series of Air Turbine Motors® are sealed for wet environments. In a wet environment, turn on the air supply to your Air Turbine Motor® **before** you turn on the coolant flow. **At the end of the cycle turn the coolant off first.** Only after the coolant flow is off, **then** you can turn off the air flow to your tool.

Selecting the Correct Cutting Tool

Ensure your cutting tool is rated for the rotational speed you are using. The 740MX runs at 40,000, 50,000 or 65,000 rpm. Your tool must also be balanced and truly concentric to operate at the high speed of Air Turbine Motors®. Incorrect tool selection results in unbalanced rotation or overloading, which will result in stress on the bearings and premature failure. The stick-out extension length of the cutting tool from your collet should optimally be no more than 3 times the diameter of your cutting tool.

Installation or Removal of Collet and Cutting Tool

1. Take the wrench included with your Air Turbine Motor® and insert it to the wrench flat of your Air Turbine Tool's shaft.
2. Take the ER11 collet wrench included with your Air Turbine Motor® and apply it on the collet slot as shown in the left diagram. Turn the wrench counterclockwise to release the current cutting tool.
3. After the cutting tool is free, continue to turn the collet nut counterclockwise with the ER11 collet wrench to fully remove the collet nut and release the existing collet. Remove the wrench from the shaft.
4. Remove the existing collet from the shaft and replace it with the new collet. Re-apply the collet nut by turning it clockwise on the shaft. **The 740MX requires 7 ft-lbs of torque to tighten.**
5. Insert the new cutting tool by sliding it into the shaft of your tool. Ensure that the new cutting tool goes completely through the collet as shown to the left. **The stick-out extension length of the cutting tool from your collet should optimally be no more than 3 times the diameter of your cutting tool.**
6. Re-insert the wrench onto the wrench flat of your Air Turbine Tool's shaft and turn the collet nut clockwise until it's firmly held. **Do not over tighten the collet nut.** The 740MX requires 7 ft-lbs of torque to tighten.
7. Insert the collet wrench into the collet nut and turn it clockwise to ensure the new collet and cutting tool is firmly held.



WARNING

Connection to air supply starts motor rotation. Do not connect air to your tool until installation is complete.

Tel:+1.561.994.0500 • www.airturbinetools.com • ask@airturbinetools.com